## How to reset your A/C allure



 Locate your breaker panel (usually located behind the bedroom door)

- 2. Look for the Panel Schedule
- 3. Find the ACU-4 breaker

PANEL SCHEDULE					
1)	1P-20A	Lighting	2)	1P-20A	Lighting
3)	and the second se	R-Living Room	4)	1P-20A	R-Master Bedroom
5)	and the second s	R-Bedroom/Doorbel X7mr	6)	1P-20A	R-Dining
7)	1P-20A	R-Master Bath	8)	1P-20A	R-Bath
7) 9)	1P-20A	R-Kitchen	10)	1P-20A	R-Kitchen
11)	1P-20A	R-Kitchen Refrigerator	12)	1P-20A	<b>R-Kitchen Microwave</b>
13)	1P-20A	R-Kitchen Dishwasher	14)	1P-20A	R-Telecom/Booster Fan
15)	1P-20A	R-Disposal	16)	1P-20A	Smoke Detectors
17)	2P-30A	R-Washer/Dryer	18)	2P-30A	Water Heater
19)		+	20)		
21)	2P-50A	R-Range	22)	2P-40A	ACU-4
23)		Peret	24)	+=+	
25)	PFB	Rent Land	26)	PFB	and the second
27)	PFB	Participal and a second	28)	PFB	- LOT BALL
		Contraction of the local division of the loc	-		100

4. Reset the breaker:

In order to properly reset the breaker, you must turn switch to off position all the way, and then put it back to "ON". If you switch it on without turning it off first, it will not properly reset.

5. Please, give 15 minutes for A/C to start up.